

Scotle Air-cooled 4 IN 1 Handheld Laser Welding Machine (SUP23T, BWT Source) Manual



Shenzhen Scotle Technology Group Limited

No.14, 2F, Building Y1, Bantian Street Creative Park, Longgang District, Shenzhen, Guangdong, 518129 China

www.scotle.com

Content

1. Safety Tips	5
1.1 Safety Instructions	5
1.2 Potential Hazards	6
1.3 Protective Housing and Interlocking System	7
1.4 Safety Labels	9
1.5 EU Agency Information	9
1.6 Product Nameplate	10
1.7 Compliance to Standards for CE Marking	10
2. Machine Information	11
2.1 Overall Display	11
2.2 Laser Source Introduction	12
2.3 Handheld Gun Introduction	17
2.4 Screen Control System Introduction	20
2.5 Wire Feeder Introduction	29
3. Machine Installation Guide	32
3.1 Unbox	32
3.2 Package List	34
3.3 Preparation Work Before Startup	34
3.4 Wire Feeder Connection	35
3.5 Operating Interface	40
3.5.1 Interface Home Page	40
3.6 Safe ClipInsert the ground wire into the corresponding terminal at the back of the machine	44
3.7 Start Up Machine	45
4. User Guide	47
4.1.Welding Mode	48
4.2 Cutting Mode	52
4.3 Welding Seam Cleaning Mode	54
4.4 Cleaning Mode	57
5. Machine Maintenance and Upkeep	64
5.1 Maintenance for Protective Lens	64
5.2 Regular Cleaning of Machine	64
6. Q&A	65
6.1 No Laser Emission	65
6.2 The Welding Machine Can Not Continuously Welding	66



6.3 The Welding Is Not Firm or With Ugly Result	67
6.4 Product common problems and treatment measuresWarning! Before dealing with any problem, all power must be cut off to avoid any danger!	68
7. After-sales Statement	71

Foreword

Welcome to use the handheld laser cleaning products produced by Shenzhen Scotle Technology Group Ltd. For better use and maintain your laser equipment, please read this manual carefully before using this product. All laser operators must use personal protective equipment when using our laser machines. To avoid the hazards caused by lasers, please strictly follow all warnings and safety tips in this manual to prevent unnecessary risks. Our laser machines are safe and reliable by following this manual and applying reliable laser safety measures.

If the user has any comments and suggestions during use, please feel free to give us your advice to help us continue to revise and improve. Thank you again for using the products of Shenzhen Scotle Technology Group Ltd.!

During the operation, maintenance and service of this equipment, in order to ensure the safety of the operator, please do not disassemble the equipment privately. This product has no parts, components and assemblies that the user needs to repair by himself. Our company will not provide warranty service for damage to the equipment or accessories caused by the laser dismantled privately.

Our company certifies that this laser machine has been thoroughly tested and inspected. The inspection before shipment meets the published specifications. When you receive the machine, please check whether the packaging and parts are damaged. If so, it may have occurred during transportation. If the damage is obvious, please keep evidence and contact Shenzhen Scotle Technology Group Ltd.

1. Safety Tips

The laser level of this machine is class 4. To ensure the safety of the user, please read the safety tips carefully before using the machine.

1.1 Safety Instructions

- ① When using this machine, please use a suitable grounded power supply and corresponding voltage.
- ② Before operation, please wear special fiber laser protective glasses and gloves; do not look directly at the laser to avoid damage to the eyes or skin.
- ③ Before emitting the laser, the dust-proof cover of the field lens needs to be removed;
- ④ Make sure that all optical components are below eye level, and pay special attention to the height of the eyes when sitting on a chair.
- ⑤ Avoid operating this machine in a dark, humid, hot, and unventilated environment.
- ⑥ Do not turn on the laser without an optical coupling fiber or the optical output connector.
- ⑦ Make sure to operate the machine only after receiving safety training.
- ⑧ Keep the machine clean, maintain the machine regularly to prevent foreign matter from entering the cavity, otherwise it will cause functional contamination and functional impact of related parts;

For technical support, please contact the corresponding after-sales service department:

eBay after-sales:

AliExpress after-sales:

Amazon after-sales:

B2B and official website after-sales: sales10@scotle.com

1.2 Potential Hazards

① Radiation Hazards

The laser cleaning process will generate visible and invisible radiation. The high-energy laser beam of the pulse laser cleaning machine directly irradiates the human body, especially the eyes and skin, which may cause serious damage on eye includes retinal burns. To prevent these injuries, special laser protection glasses must be worn, the safety barriers and warning signs must be set up in the operating area.

② Skin Hazards

Exposure to infrared and ultraviolet radiation during laser cleaning can hurt the skin. Laser sparks can also cause burns. Laser processing can transfer a lot of energy into the parts to be cleaned, so the parts will be very hot even after cleaning. It is necessary to take precautions to prevent skin damage by wearing protective clothing such as flame-resistant gloves, hats, leather aprons, and other flame-resistant clothing, sleeves and collars should be buttoned too.

③ Fire Hazards

If flammable or combustible materials are close to the laser work area, the heat and sparks generated during the work process may cause a fire or explosion. Laser cleaning work can only be carried out when there are no flammable materials in the area. Fire extinguishers should be located nearby, easily accessible, and have personnel trained in their use.

④ Smoke Hazards

Laser cleaning "fumes" can consist of very fine particles and gases. Fumes and gases come from a combination of laser cleaning materials or shielding gases, paints, coatings, chemical reactions, and air pollutants. These fumes can adversely affect the lungs, heart, kidneys, and central nervous system. So better use this product in a ventilated environment and use a fume extraction system if necessary.

⑤ Machine Damage

Optical accessories relevant to the laser, such as light-sensitive elements that may be damaged from

exposure to the laser light, video cameras, photo multipliers and photo diodes, need related protections.

1.3 Protective Housing and Interlocking System

① The structure and layout of the shield should be designed to ensure that the human body cannot directly enter the dangerous area. Shields should be closed mechanisms, meeting specific safety distance and opening size requirements when a mesh structure is required.


② For the installation of the laser room, should follow the guidance of the professional design, installation team, in accordance with the drawings.

③ The installation of the laser room also includes components such as the house body, internal frame, maintenance door, observation window, safety door, lighting, optical fiber hanging device, monitoring, dust removal, light source room, air conditioning, anti-collision fence.

④ The safety door of the laser room should be connected with the product remote control chain connector. When an external person intervenes and opens the door, the terminal of the connector opens and the laser machine stops launching. Prevent external personnel or unauthorized personnel from exposure to dangerous radiation.




⑤ Use of interlocking system:

In the laser control zone, walls and doors can limit the hazard of laser radiation. The interlocking system connected to the door can actually operate to restrict access when a hazard occurs, allowing only trained, authorized and appropriately protective equipment to enter.



1.4 Safety Labels

As shown in the following table, all safety warning signs during the operation of the handheld laser cleaning machine (not limited to the signs on the laser body) include:

		
<p>Warning label – Hazard symbol</p>	<p>Explanatory label (Take 1000W as example)</p>	<p>Alternative label for laser aperture</p>
		
<p>Alternative label for Class 4</p>	<p>Must be grounded</p>	<p>Electrical Hazard</p>

1.5 EU Agency Information

E-CrossStu GmbH

Felix-Dahn-Str 4

Stuttgart 70597

E-CrossStu@web.de +49 71191222069



Product name : 4 IN 1 Laser Welding Machine

Model : LWM-YHY

Rated voltage :220V

Rated current : 15A

Manufacturer : Shenzhen Yuhaiyuan Technology Co., Ltd

Address: Longgang District Yayuan Road Chuangyiyuan

Y1-2-14 Shenzhen China

Made in China

1.6 Product Nameplate

huizhoushiyunshengshukongshebeiyouxiangongsi	
Dogain 4 IN 1 Laser Welder	
Product name: Dogain 1200W Laser Weder	
Model NO: Dogain 1200W	
Rating Voltage : 220V	Rating Frequency: 50/60Hz
Laser Power:1200W	Rating Power:3800W
Phase:L+N+PE	Class 4 Laser
Origin:China	Mfg year : 2026 . 05
Address :	
huizhoushihuiyangquqiuchangjiedaoxihucunweipangtianhaichuangxinke jiyuanAdong5lou 512200 China	



1.7 Compliance to Standards for CE Marking

This product complies with the European Union Harmonized legislation, only complies with the above directives and standards when installed in accordance with the manufacturer's specifications.

The European Community requirements for product safety in the 2006/42/EC Machinery (MD)

This Directive requires that lasers comply with the standard:

EN ISO 12100:2010

EN 60204-1:2018

EN ISO 11553-1:2020/A11:2020

EN ISO 11553-2:2008

EN 60825-1:2014/A11:2021

2. Machine Information

2.1 Overall Display





2.2 Laser Source Introduction

In order to guarantee the fiber laser is operated safely (including personnel safety, equipment safety, production safety), ensure the product remain its best condition for a long time.

We compile this document with important safety, operating, maintaining and other information. Please take time to read and understand this User's Guide and familiarize yourself with the operating and maintenance instructions before using the product.

2.2.1 Laser Source Safety Signs:

SYMBOLS	DESCRIPTION
	<p>WARNING :</p> <p><i>Refers to a potential hazard that may leads to a personal injury or death.</i></p>
	<p>CAUTION :</p> <p><i>Refers to a potential hazard on product, or a potential physical injury on personnel</i></p>
<p>NO SYMBOL</p>	<p>IMPORTANT :</p> <p><i>Refers to any information regarding the operation of the product. Please do not overlook this information.</i></p>

2.2.2 Laser Classification

This series of lasers emit invisible laser radiation around a wavelength of $1080 \pm 3\text{nm}$.


The average power of the products is ranged from 10% to 100% at a maximum power range from 1000W to

4000W, which classifies the series of lasers Class 4 laser instrument.

Direct or indirect exposure of this level of light intensity may cause very serious damage to the eyes or skin.

In view of this, appropriate and approved laser safety protective glasses must be worn all the time while the laser is operating.

At the same time, no directly or reflectively emit on your skin.

	<p>WARNING :</p> <p><i>The laser safety protective glasses are selected according to the wavelengths of the output laser. The users must ensure that the laser safety protective glasses covered the entire range of wavelengths of the laser emission.</i></p>
---	--

2.2.3 Laser Source Operation Conditions

The basic operation conditions are listed in the table followed:

Item	Value
Supply Voltage(V)	220±10% VAC 50/60Hz
Placement	Flat, upright, no vibration and impact
Environment Temperature	5~40℃
Relative Humidity	30%RH~70%RH
Electromagnetic Environment	Avoid too strong electromagnetic interference, which may lead to false alarm of laser

Note:

-
- ① It is very easy to be damaged when the QBH getting scaling, and there is no warranty in this case.
 - ② The output of the laser is connected with the cable. Please check the end surface of the quartz head carefully to prevent dust or other pollution. Lens-cleansing paper must be used when cleaning is necessary.
 - ③ Never installing the laser output with the processing system when the equipment is power on.
 - ④ The protective glasses should be worn all the time.

**CAUTION:**

(1) Never make this product work in high humidity (> 95%) ,though the product shave an excellent adaptability to the high humidity environment

(2) Never let this product work below the ambient dew point temperature(like the table 2.2)

Maximum Relative humidity (%)	20	30	40	50	60	70	80	90	95
Room Temperature(°C)	Ambient Dew Point (Td-°C)								
10	-11.9	-7	-0.3	0	2.5	4.8	6.7	8.4	9.2
15	-7.9	-2.3	1.5	4.6	7.3	9.6	11.6	13.4	14.2
20	-3.5	2	6	9	12	14.5	16.5	18	19
25	0.5	6	10.5	14	16.5	19	21	23	24
30	4.6	10.5	15	18.5	21.5	24	26	28	29
35	8.5	15	19.5	23	26	28.5	31	33	34
40	13	20	24	27.5	31	33.5	36	38	39
			Temperature range for laser operating						

NO SYMBOL	<p><i>IMPORTANT :</i></p> <p><i>The lifetime of the laser will be shortened and the output power will degrade while the cooling system working at a higher temperature for too long time. Please ensure the cooling system is enough and the temperature is suitable.</i></p>
--------------	--

2.2.4 Laser Source Parameters

The characteristic parameters of the air-cooled series fiber laser that power ranged from 1200W to 1800W are demonstrated as follow:




Number	Performance Specifications	Test Conditions	Minimum value	Typical value	Maximum value	Unit
1	Operating Mode	Continuous				
2	polarization state					
3	Output power	1200				W
4	Output wavelength	100% continuous	1070	1080	1090	nm
5	Adjustment range	100% continuous	10		100	%
6	Spectral bandwidth (3 dB)	100% continuous		4	6	nm
7	Power Stability	25°C@24H		±2	±3	%
8	Beam quality	14μmQBH output			1.5	-
9	Maximum modulation frequency				10	kHz
10	Output fiber length			10		m
11	Output Format	Standard QBH				
12	Operating voltage			220		VAC
13	Operating temperature		-20		45	°C
14	Humidity in the work environment				85	%
15	Cooling method	Air				
16	Size	132*289*433				mm

2.3 Handheld Gun Introduction

For more information, please check the "manual for SUP 31F welding gun".

2.3.1 Handheld Gun Display



QBH connector	Complete the access and lock of the optical fiber connector
Collimating lens	Collimating lens: Complete the fiber collimation function and collimate the incident laser into a parallel beam.
Galvo-lens module	A component composed of a reflector and a motor is used to vibrate and reflect the collimated parallel laser at a certain angle , changing the direction of the original beam and the shape of the spot.
Focus lens	Focus the reflected beam into a convergent beam with high power density.
Protective lens	The protective glass can protect the focusing lens from the damage of returning slag and prolong the service life of the focus lens.
Copper nozzle/ Scale tube	Guide the focused beam to the work piece, and generate high-speed airflow to protect the molten pool from oxidation to achieve high-quality welding results. You can also adjust the focus distance by adjusting the Scale tube


2.3.2 Configuration Parameter

Parameter name	Technical index
Maximum applicable laser power	3000W
Input voltage	220V ± 5% AC 50/60Hz
Installation environment	Flat, no vibration and impact
Working environment temperature	10~40℃
Working environment humidity	< 70 %
Cooling-down method	Air cooled
Applicable wavelength	1080nm (±10nm)
Welding protective gas	Nitrogen. Argon. Helium
Collimator	D16*4.5/F60
Focus lens	D20*4.5/F150
Reflector	30x14xT2

Protection lens specifications	D18*T2
Maximum air pressure support	10~15L/min (20℃ 0.15MPa)
Focus of vertical adjustment range	±10mm
Scan width--welding	0~8mm
Scan Width--cleaning	F150-0~30mm
	F800-0~120mm
The net weight of the welding gun	0.58kg

2.3.3 Welding Head Copper Nozzle

Handheld Laser Welding Head Copper Nozzle



Different copper nozzle applies to different materials welding.

For example, AS-12 copper nozzle mainly used for welding wire 1.0 at inner Angle feed (AS-12 basic universal);

AS-12: The filaments below 1.2mm are generally used for flat Angle, inner Angle and outer Angle welding;

BS-16: The filaments below 1.6mm are generally used for flat Angle, inner Angle and outer Angle welding;

CS-12: The filaments below 1.2mm are generally used for outer Angle welding;

FS-16: The filaments below 1.6mm are generally used for outer Angle welding;


C: For non-wire feeding, used for outer corner welding;

ES-12: Filaments below 1.2mm are commonly used for outer corner sheet welding.



2.4 Screen Control System Introduction

2.4.1 Welding System Homepage



①This interface can see the current process parameters (this page can not be modified process) and real-time alarm information.

②The default is ON, the red light is LINE by default, and the welding mode is continuous.


When the enabling is turned off, the enabling signal will not be sent to the laser and can be used to test the outlet function. Close the red light indicator, the motor stops swinging, and the red light is a point to adjust the

center position. The welding mode is divided into continuous and spot welding. When the spot welding is selected, the spot welding type needs to be set on the setting page.

③The safety lock is divided into gray and green. When the metal clip is clamped on the processing piece and the copper nozzle of the gun contacts the processing piece, the 5 and 6 feet of the signal interface 1 are connected, and the safety lock indicator is displayed as green. At this time, the light can be realized according to the trigger.

④Click on the upper right corner to switch to the cleaning mode.

2.4.2 Page in “Technology”



①The process interface contains the process parameters of debugging, click the box (red) to modify, click OK, and then save in the quick process, click import (modify-save-import).

② The scan speed range is 2-6000mm / S, and the scan width range is 0 - 6mm. The scan speed is limited by the scan width, which is:

$$10 \leq \text{scan speed} / (\text{scan width} * 2) \leq 1000,$$

If the limit is exceeded, it automatically becomes the limit value. When the scan width is set to 0, it does not scan



(it is a point light source)

(The most commonly used scanning speed: 300mm / S, width of 2.5-4mm).

③The peak power should be less than or equal to the laser power of the parameter

page (if the laser power is 1500W, this value is not higher than 1500).

④Duty cycle range 0 to 100 (default 100, usually not changed).

⑤The pulse frequency range is recommended from 5-5000Hz (default 2000, usually no modification).

⑥Click the HELP button on the top right to get more relevant parameter explanations.

⑦After modifying the parameters, you can see whether the import is successful on the home page

⑧Reference process, can be used in the small program process reference matters need attention:

Some lasers cannot emit light with less than 10% power. When the peak power of the process page is less than 10% of the maximum power of the laser on the set page, all output signals are normal, but they may not emit light.

The duty cycle is 100%, usually does not need to change, when the pulse frequency does not work. If you need to use it, please adjust it according to the actual requirements. Example: Peak power of 300W, duty cycle of 50%, and pulse frequency of 1000Hz. At this time, the light cycle is 1mS, 0.5mS to 300W light, 0.5 mS does not light, the cycle, the air at the welding burst, abnormal sound is normal phenomenon. The actual situation is based to the laser parameters.


Click on the Help button at the top right of the screen to get more relevant parameters.

2.4.3 Page in "Setting"



Click "Settings" on the home page, enter the password 123456 on the password input page of the pop-up window, and then enter the Settings page.


- ① Click "Language", you can change the language you need, total 19 languages optional.
- ② The laser power set up to machine power, please fill in correctly.
- ③ The default air delay default 200ms, range 0 ms to 3000 ms.
- ④ From N1% of process power to 100%; from 100% of process power to N2; (as shown in the figure below):



Generally preset switch light power 20%, switch light step time 200ms;

- ⑤Silk delay compensation is the advance time relative to the light signal, which can be used with the withdrawal function, not set by default;
- ⑥ The maximum value of the three temperature alarm valves is 70℃ . When the value is set to 0, the temperature is not detected, and the buzzer alarms when the measured temperature is greater than the set value;
- ⑦ Scan correction coefficient = target line width / measured line width, range from 0.01 to 4. Generally set to 1;
- ⑧ Laser center offset-3~3mm, decrease to the left, increase to the right, applied to adjust the red axis light center;
- ⑨ Air pressure / water cooler / laser alarm level signal is low level, and when this alarm signal is used, the alarm level here should be set to the same with the alarm level of external equipment;
- ⑩ The spot welding duration is the light output time in each cycle in the spot welding mode, and the spot welding interval time is the light stop time in each cycle in the spot welding mode;
- ⑩ Click on the Help button at the top right to get more relevant parameter explanations.

2.4.4 Page in “Monitor”



Laser welding system

Monitor

Input signal status		Output signal status		Basic device information	
Laser trigger signal		PWM signal	<input type="radio"/> 0 V	Equipment Authorization	Termination of authorization
Secure lock signal		Laser enable signal	<input type="radio"/> 0 V	Equipment number	0
Laser alarm signal		Analog voltage	<input type="radio"/> 0 V	Manufacturer number	0
Water cooler alarm signal		Gas valve enable signal	<input type="radio"/> 0 V	System Version	123 - 123 - 803
Pressure alarm signal		Wire feeding enable signal	<input type="radio"/>		

Power state		Auxiliary settings	
24V supply voltage	0 V	Communication status	Not synced
+15V supply voltage	0 V	To lock up being	0 mS
-15V supply voltage	-0.1 V		0
24V current	0 mA		0
±15V current	0 mA		0

diagnose Return

This page displays the status of each signal and the equipment information.


① Input signal status

Laser trigger signal: when the user externally controls the 7 and 8 feet of the signal interface 1, this state is changed from gray to green.

Safety lock signal: normal short contact, this state changes from gray to green.

Laser / air pressure alarm signal: monitor the real-time level status of these interfaces.


Water cooler alarm signal is invalid for an air cooled laser welding machine



② Output signal status

When the signal is output, the signal in this area changes immediately and can be directly visualized.

The monitoring signal is the circuit signal detected in real time, which will fluctuate in a certain range and have an error of less than 0.3V with the final output signal.




③ Basic information of the equipment

Equipment authorization: click to encrypt the use time of the equipment, When the equipment is used for more

than the set time, the authorization will be terminated and the system will stop working. Factory default is long term effective, if you need encryption and decryption, please contact us for inquiry.

System version: three sets of numbers, the first group is the hardware version, the second group is the micro controller program version, the third group is the touch screen version.



④ Power status

The real-time power supply voltage and current of the device are shown. Due to the update of the algorithm, the data accuracy continues to indicate that there will be some differences in different versions of different versions, which is a normal phenomenon. Mainly through the power supply voltage to help after sales power supply troubleshooting.


24V supply voltage	0	V
+15V supply voltage	0	V
-15V supply voltage	-0.1	V
24V current	0	mA
±15V current	0	mA

⑤ Communication status

"Communication status" indicates the communication between the touch screen and the motherboard, if not synchronized, check the screen cable.

"Anti shake" is used to deal with poor contact with safe locks, which range from 0 to 300 ms. Click "Device authorization box" to set the parameter range on the password page.

The password is "fffffaa300" where "fffffaa" indicates the lock anti-shake parameter and cannot be changed. "300" means 300ms. The effect is that when the trigger signal is normal and the disconnection time of the safety lock signal is <300ms. Material welding used to deal with poor surface performance and unstable conductivity (e. g. rust) is usually set to 0. disconnection time of the safety lock signal is <300ms, Material welding used to deal with poor surface performance and unstable conductivity(e. g. rust) is usually set to 0.



"Motor driver temperature" and "protective mirror temperature" represent the measured real-time temperature of the two parts.

"Motor driver temperature" affects the motor swing performance of the environment. If the environment is poor, it will lead to the abnormal temperature increase, affect the laser scanning speed, and then lead to the decrease of weld quality, The lens temperature reflects the working state of the lens to help determine whether the lens is damaged.


Auxiliary settings		
Communication status	Not synced	
To lock up being	0	mS
Motor drive temperature	0	°C
Protective lens temperature	0	°C

⑥ Diagnose


Click the diagnostic button to enter the diagnostic interface. Use to measure whether the signal port has an

actual output, usually the output value is consistent with the detection value, When inconsistent, the load is abnormal, such as when the laser does not light, through the single port with the laser monitoring software or multi meter measurement, the real reaction signal is emitted

Laser welding system

diagnose

Output signal	Theoretical output value	Detection value	Switch control
PWM signal (V)	0	0	
Laser enable (V)	0	0	
Gas valve enable (V)	0	0	
Analog voltage (V)	0	0	
Wire feeding enable	<input type="radio"/>	Observe the status of the wire feeder or measure with a multimeter	



2.5 Wire Feeder Introduction




Number	Name	Notes
1	Screen	7-inch touchscreen
2	Side door of the chassis	
3	Switch	The red light is on when 220V is on
4	Wire outlet	
5	Nameplate	
6-2	Six-core navigation socket	Process Library Edition-Control Signal Interface
7	Three-core navigation socket	220V power interface

2.5.1 Technical Parameters

Supply voltage	220V±10%AC 50/60Hz	
Operating ambient temperature	-10 to 50°C	
Maximum power	84W	
Wire feeding speed	15 to 600cm/min	
Wire feeding mode	Continuous mode,Pulse mode	
Applicable to welding wire	Carbon steel solid core wire, stainless steel solid core wire, aluminium solid core wire	
Net weight	12.8±0.3kg	
Suitable for wire reels	Shaft diameter	Min 50mm
	Outer diameter	Max 300mm
	Width	Max 105mm
	Weight	Max 20kg

2.5.2 Wire Feeder Set Up



The screenshot displays the control interface for the Laser welding system, specifically the Wire feeder setup screen. The interface is divided into several sections:

- System Overview (Top Left):** Shows system status including Scan speed (300.0 mm/s), Scan width (3.00 mm), Peak power (350 W), Duty cycle (100 %), and Frequency (2000 Hz). It also includes control buttons for Laser enable (ON), Indication of red light (LINE), Welding mode (Continuous), and Secure lock.
- Navigation (Top Right):** Features buttons for Home, Technology (highlighted with a red box), Setting, and Monitor.
- Wire feeder Setup (Main Area):**
 - Common parameters:** Start-up delay (0 ms), Retract length (10 mm), Supplement length (10 mm), Supplement delay (0 ms), Manual feed speed (300 cm/min), and Manual Retract speed (300 cm/min).
 - Continuous mode parameters:** Feeding speed (50 cm/min), Manual wire feeding, and Manual wire retract.
 - Pulse control mode parameters:** Average speed (60 cm/min), Pulse cycle (200 ms), Pulse feed ratio (30 (25%-80%)), Manual wire retract, and Run button.
- Equipment Basic Information (Bottom Right):** System version (231-607) and Communication status (Synced).
- Material Selection (Bottom Center):** A list of materials with their thicknesses: 1.0, 2.0, 3.0, 4.0, 5.0, and 6.0 mm.



The wire feeder is used with the welding machine and shares a 7-inch touch screen with the welding system with a resolution of 1024 × 600. Get into the “Technology”page, you will see “wirefeeder-Connected” after connected wirefeeder to the machine, click”wirefeeder-Connected” to get into Wire feeder page, so you can modify the wire feeder parameters.

Button name	Function	Remark
Pulse mode / Continue mode	Click to switch to another mode	Pulse mode for fish scale welding
Run/Stop	Click to switch to the corresponding state	The two are mutually exclusive, and the motor does not rotate when shows [Stop]
Manual wire feeding /manual wire retract	Click the motor forward / reverse	Manual wire feeding speed ≠ wire feeding speed
Feeding speed	Adjust the wire feeding speed during welding, the range is 15 ~ 600 cm/min.	Valid in continuous mode
Average speed		
Pulse cycle		Adjust the length of a single fish scale pattern
Pulse feed ratio	Adjust the degree of fish scales, the smaller the scales, the more obvious they are.	Valid in pulse mode
Start-up delay	Set up the time delay of wire feeder after the gun trigger is pressed. Range 0 ~ 2000 ms, usually set to 0.	Overall effective
Retract length	When the wire is broken, the motor reverses to assist in breaking the wire. The range is 0 ~ 100mm, usually set to 10.	
Supplement length	After the retraction, the motor rotates forward to balance the retraction.The range is 0 ~ 100mm.	
Supplement delay	The interval between wire filling and retraction can avoid wire sticking due to wire filling too quickly.Range 0 ~ 2000 ms. Usually set to 0.	
Manual feed speed	Wire feeding speed when the motor rotates	



	forward, used for manual debugging. Range 15 ~ 600 cm/min. Usually set to 300 cm/min.	
Manual retract speed	Retraction speed of motor reversal, for manual debugging. Range 15 ~ 600 cm/min. Usually set to 300 cm/min.	
System version	Display the main control board version and system version	Avoid mixing the main control board and the screen

3. Machine Installation Guide

3.1 Unbox

Machines are packaged in wooden boxes, while wire feeders are packaged in cardboard boxes. If there are any signs of external damage to the packaging, please check if the unit is damaged and immediately notify the shipping agent Reason. When you remove the unit from the packaging box, please be particularly careful to ensure that the optical fiber is not broken or damaged. The system documentation includes a comprehensive packing list. After receiving the product, please check all items against this list.

If any items are lost or the unit is significantly damaged, please contact us immediately. If there is obvious damage or suspicion to the crew Seemingly damaged, do not attempt to install or operate the laser device under any circumstances.

Laser is a precision and valuable item. please follow the following steps to disassemble and assemble the packaging box:

- (1) Place the equipment of this product on a flat surface according to the packaging box label.
- (2) The top cover packing box shall be removed step by step according to the identification of the top cover packing box. After removal, the top foam baffle shall be removed.
- (3) The laser is connected to the fiber optic cable of the gun head, please be careful to remove it and ensure the bending radius of the fiber optic cable armor > 175mm.
- (4) Remove the foam shield and take out the supporting items.

(5) Please check the accessories against the packing list.

(6) Please keep all items unpacked properly to prevent future transportation or storage needs.



Machine wooden box



Wire feeder carton box

3.2 Package List

Packing List

	 Safety goggles	 Safe Clip
	 Power Cord	 Wrench
 8Pcs Welding Nozzle	 Wire Feeder Tube	 5pcs D18*2

3.3 Preparation Work Before Startup

- (1) Connecting the Argon gas / Nitrogen gas, The flow rate of the gas needs to reach 15L/min)
- (2) (Noticed: When using welding and cutting function, need to use with protective gas such as Argon / Nitrogen. But the gas can not be shipped with machine, so customer need to prepare themselves. Recommend use above 99.9% pure Argon 4.6, it will influence welding effect.)



- (3) After connected air pump or protective gas, Adjust the output pressure of the gas cylinder to 0.2 MPa or higher.

3.4 Wire Feeder Connection

The wire feeder and the welding system share the same 24V power supply built in the machine. The wire feeder parameters effective when the wire feeder connect to the welding system (machine) through the 6-core aviation plug interface on the back of the wire feeder.

3.4.1 Selection of Wire Feeding Tube and Wire Feeding Wheel

Please select the corresponding wire feed wheel and wire feed tube according to the welding wire material and diameter, and avoid bending the wire feed tube during use.

Wire feeding wheel model	Materials		Carbon steel, stainless steel
	Wire feeding wheel - V shaped	standard	ϕ 0.8/1.0mm ϕ 1.2/1.6mm
		customized	ϕ 1.6/2.0mm
	Materials		aluminum
Wire feeding wheel - U shaped	customized	ϕ 0.8/1.0mm ϕ 1.2/1.6mm ϕ 1.6/2.0mm	

Machine standard with two pcs of ϕ 0.8/1.0mm and two pcs of ϕ 1.2/1.6mm V-shaped wire feeding wheels, which are used for carbon steel welding. If need for wider weld seam, then need ϕ 2.0/2.5mm customized wire feeding wheels.




Schematic diagram of **wire feeding tube** and **wire feeding wheel**

If use for aluminum welding wire, need to replace the U-shaped wire feeding wheels and the matching black graphite wire feeding tube. These customized parts need to buy additionally.



3.4.2 Wire Reel / Wire Feeding Wheel Installation



No.	Name	Remark
1	Wire feeding wheel box	
2	Damping shaft	Maximum load: 20kg
2-1	Damping shaft - locating pin	Wire reel positioning

When installing the wire reel, should pay attention to:


- ① Select the welding wire according to the welding material;
- ② The welding wire passes through the center of the groove;
- ③ Use the wire feeding wheel that matches the welding wire. For example, if use the V-shaped $\phi 1.0$ stainless steel welding wire, the side of the wire feeding wheel marked [V1.0] should face outward;
- ④ The positioning hole of the wire reel should be aligned with the positioning pin of the damping shaft, so that the wire reel and the damping shaft can rotate smoothly to avoid friction between the wire reel and the damping shaft which may cause unstable of wire feeding.

3.4.3 Wire Feeding Tube Installation

When installing the wire feeding tube, should pay attention to:

- ① Loosen the locking screw and insert the wire feed tube till the wire feed tube does not rub against the wire feed wheel and the welding wire can be easily inserted;
- ② After inserting it into the appropriate position, tighten the screw till the wire feed tube does not shake when it is manually cranked.





3.4.4 Connect Wire Feeding Tube to Welding Head

When connecting the wire feeding tube to welding head, should pay attention to:


- ① Select the corresponding connection block according to the welding head model;
- ② Make sure that the welding wire is stuck in the copper nozzle slot before tightening the hexagon socket screw;
- ③ Select the wire guide nozzle according to the wire diameter;
- ④ Adjust the length of the wire guide tube according to the actual focal length of the welding head.



3.5 Operating Interface

The wire feeder is equipped with a 7-inch touchscreen with a resolution of 1024x600.

3.5.1 Interface Home Page



Number	Key names	Functions	Notes
1	Pulse mode/continuous mode	Click to switch to another mode	Pulse mode is used for fish-scale pattern welding
2	Settings	Click to enter the Settings page	
3	Run/Stop	Click to switch to the corresponding state	Both are mutually exclusive, and the motor does not rotate when [stop]
4	Manual wire feeding/manual retraction	Click the motor forward/reverse	Manual Feeding speed is not equal to Feeding speed
5	Status indication	The green light indicates that the motor is running	Click invalid
6-1	Feeding speed	Adjust the Feeding speed during welding	Effective in continuous mode
6-2	Average speed		It takes effect in Pulse mode
7	Pulse-specific parameters	Display dedicated parameters for Pulse mode	

3.5.2 Interface Settings page

Laser welding wire feeding system Help

Continuous mode setting

8-1

Feeding speed (cm/min) ▲ ▼

Start-up delay (ms) ▲ ▼

Retract length (mm) ▲ ▼

Supplement length (mm) ▲ ▼

Supplement delay (ms) ▲ ▼

Language English

Manual feed speed (cm/min) ▲ ▼

Manual Retract speed (cm/min) ▲ ▼

System version - -

Save

Return

Laser welding wire feeding system Help

Pulse mode setting

9

Common parameters

Start-up delay (ms) ▲ ▼

Retract length (mm) ▲ ▼

Supplement length (mm) ▲ ▼

Supplement delay (ms) ▲ ▼

Manual feed speed (cm/min) ▲ ▼

Manual Retract speed (cm/min) ▲ ▼

Pulse control mode parameters

Average speed (cm/min) ▲ ▼

Pulse cycle (ms) ▲ ▼

Pulse feed ratio (25%~80%) ▲ ▼

Equipment basic information

System version - -

Language English

10


Save

Return

Number	Key names	Functions	Notes
8-1	Feeding speed	Adjust the Feeding speed during welding	Effective in continuous mode
8-2	Average speed		Adjust the length of individual fish scales
	Pulse cycle		
	Pulse feed ratio	Adjust the clarity of the fish-scale pattern;the smaller it is,the more obvious it becomes	
9	Start the delay	Delay wire ejection relative to the light signal of the welding head	Global effect
	Retraction length	When the wire breaks,the motor reverses to assist in breaking the wire	
	Patch length	The motor rotates forward after the retraction for balancing the retraction	
	Wire filling delay	The interval between threading and redrawing to avoid threading too fast and sticking	
	Manual wire feeding speed	The wire feeding speed for the forward rotation of the motor,for manual debugging	
	Manual retraction speed	Motor reverse retraction speed for manual debugging	
10	System Version	Show the master board version and interface version	Avoid mixing the main control board with the screen
11	Language	Click to switch the operating interface language	The system supports 19 languages

3.6 Safe Clip

Insert the ground wire into the corresponding terminal at the back of the machine.



Before turning on the laser, the safety clip must be clamped in the correct position (workpiece) to ensure that it forms a circuit with the welding head, or there will be no laser out.

In welding mode, the safety clip is clamped on the welded work piece.



3.7 Start Up Machine


- (1) Adjust the scale tube with 0mm, which is the best focal length.




- (2) Turn the main power switch on the back of the machine clockwise.



(3) Press the switch button to emit laser light, and release it to stop emitting light



(4) When welding, keep the welding head at a 45 ° with work piece you welding.



4. User Guide

Overview of 4 in 1 Laser Welding Machine:

Laser welding: Supports the welding of various materials such as metal, carbon steel, stainless steel, aluminum alloy, etc. It adopts laser beam fusion technology, with high precision and small heat affected zone, and the weld

seam is firm and beautiful.

Laser cleaning: Quickly removes rust, oil stains, oxides and other pollutants from metal surfaces without touching the work piece, making it environmentally friendly and efficient.

Laser cutting: Suitable for cutting metal sheets, with flexible operation and widely used in fields such as hardware and sheet metal manufacturing.

Weld cleaning: After welding, rust removal and oxidation layer removal should be carried out on the weld to improve welding quality.

4.1.Welding Mode

4.1.1:Select The Correct Cooper Nozzle

4.1.2: Wire Selection

(1) According to the width of the weld seam choose the diameter of the welding wire.

- Width of weld seam < 1.2mm, Recommend 0.8mm welding wire
- Width of weld seam < 1.5mm, Recommend 1.0mm welding wire
- Width of weld seam < 2.0mm, Recommend 1.2mm welding wire
- Width of weld seam < 3.0mm, Recommend 1.6mm welding wire


(2) According to the different welding plates, we need to use different welding wires (gas protected solid core

wire).


- Stainless steel = ER304 Stainless steel welding wire
- Carbon steel / Galvanized sheet = Iron wire
- Aluminum = Aluminum wire (Aluminum welding wire is recommended to use alloy aluminum of 5 series or above, which has high hardness and is not easy to get stuck)

4.1.3: Setting Welding Parameter In Control Screen


- Click “technology” , set up welding parameters



- According to your requirement to choose the parameters in process library



- If your needs are not met, you can adjust the “Scan speed” “Scan width” “Peak power” as your requirement.



4.1.4 Welding Parameters

Laser Welding Parameter (reference)								
Materials	Thickness /mm	Scan Speed mm/s	Scan width/mm	Peak power/W	Duty cycle	Frequency/Hz	Wire feed speed cm/s	Welding wire
Carbon steel	1	300	3	350	100	2000	60	1
	2	300	3	700	100	2000	60	1.2
	3	300	3	1100	100	2000	60	1.2
	4	300	3	1500	100	2000	60	1.6
	5	220	3	1800	100	2000	50	1.6
	6	220	3	2200	100	2000	50	1.6
	8	220	3	3000	100	2000	40	2
Aluminum	1	300	3	500	100	2000	60	ER5356 1.0
	2	300	3	800	100	2000	60	ER5356 1.2
	3	300	3	1400	100	2000	60	ER5356 1.2
	4	300	3	1800	100	2000	60	ER5356 1.6
	5	220	3	2000	100	2000	50	ER5356 1.6
Stainless steel	0.5	300	3	260	100	2000	80	ER304 0.8
	0.8	300	3	300	100	2000	80	ER304 0.8
	1	300	3	350	100	2000	60	ER304 1.0
	2	300	3	700	100	2000	60	ER304 1.0
	3	300	3	1100	100	2000	60	ER304 1.2
	4	300	3	1500	100	2000	60	ER304 1.2
	5	220	3	1800	100	2000	50	ER304 1.6
	6	220	3	2200	100	2000	50	ER304 1.6
8	220	3	3000	100	2000	40	ER304 2.0	

The following is laboratory data on welding and cutting, for reference only. Please refer to the actual situation for details

Air cooled Laser	1200W	1500W
Welding thickness of carbon steel and stainless steel	0.5-4mm (MAX 4.5mm)	0.5-4.5mm(MAX 5mm)
Welding thickness of Aluminum	2.5mm (MAX 3mm)	3mm (MAX 3.5mm)

4.2 Cutting Mode

4.2.1 Change The Cutting Nozzle

- Please replace the cutting copper nozzle






4.2.2 Parameter setting

- Set “Scan speed” and “Scan width” as 0mm, “Peak power” as your need, the max is the machine power.

For example, if your machine is 1500W, the max peak power is 1500W.



The following is laboratory data on welding and cutting, for reference only. Please refer to the actual situation for details



Air cooled Laser	1200W	1500W
Cutting thickness of carbon steel and stainless steel	0-5mm (MAX 8mm)	0-5.5mm(MAX 8.5mm)
Cutting thickness of Aluminum	0-2mm (MAX 2.5mm)	0-2.3mm(MAX 2.8mm)

4.2.3 Start Cutting

- Clamp the safety clip onto the work piece.
- Double click laser switch on welding gun and keep click the button, start cutting

4.3 Welding Seam Cleaning Mode

4.3.1 Change the Welding Seam Cleaning Nozzle


Please replace the welding seam cleaning nozzle, Nozzle model:C



4.3.2 Parameter Setting

- Set "Scan width" according to the width of the weld seam that is oxidized or burnt during welding

Max "Scan width" should be 8mm.



4.3.3 Start Weld Seam Cleaning

- Clamp the safety clip onto the work piece
- Double click laser switch on welding gun and keep click the button, start weld seam cleaning.

4.4 Cleaning Mode

4.4.1 Remove the Copper Nozzle



4.4.2 Replace the Cleaning Lens

- If the range of rust/Paint/Oil removal is relatively narrow, and there is no need to replace the lens. Use F150 focus lens directly.
- If the cleaning range is relatively large and more efficient cleaning is needed, please replace F800 focus lens(cleaning lens).
- At the focusing lens F800, the maximum cleaning width is 130mm.
- At the focusing lens F150, the maximum cleaning width is 30mm.

(1) Open the top cover





(2) Take out the Focus Lens




- (3) Replace the F800 focus lens, Insert the lens with the convex side facing down.

4.4.3 Mode Switch in Software and Parameters Setting


- (1) Click switch button  in welding homepage




- (2) Click "Continue"



(3) Restart the machine




(4) Go to the cleaning mode homepage



When back to welding mode, it is the same operation as above.

(5) Click technology



(6) Test with parameters from the database



(7) If your needs are not met, you can adjust the “Scanning frequency” “Scan width” “Peak power” as your requirement.




When use F150 focus lens, Scan width must $\leq 26\text{mm}$.(It is important! ! !)

When use F800 focus lens, Scan width must $\leq 20\text{mm}$.

If the parameters are not set according to this, it will burn the welding head.

When use cleaning function, peak power no more than 1200W.



4.4.4 Start Cleaning

- Clamp the safety clip onto the welding gun.
- Double click laser switch on welding gun and keep click the button, start cleaning.
- **Focus adjustment:** Move the welding gun up and down, and when the laser is strongest, it is the optimal focal length.

5. Machine Maintenance and Upkeep

5.1 Maintenance for Protective Lens

5.1.1 When the Protective Lenses Should be Replaced?

- Check the protective lens. If there is obvious burning on the surface of the protective lens, replace it directly.
- Check the white accumulating sealing ring under the protective lens. (If there is any scratch or deformation of the accumulating seal ring, it cannot be used and must be replaced immediately.

5.1.2 How to Replace Protective Lenses:

- Before operation, please clean your hands and wipe them dry, and then wipe your hands again with cotton dipped in alcohol.
- Remove the screws of the protective lens compartment cover in a relatively dust-free place, pull out the protective lens bracket, and protect it (covered by masking paper).
- Wipe the compartment opening and the inside of the compartment cover with a cotton ball dipped in alcohol, quickly insert the protective lens holder into the protective lens compartment, and tighten the screws.

5.2 Regular Cleaning of Machine

Keep the surface of the device clean to prevent dust accumulation if do not use machine for a long time.


6. Q&A

6.1 No Laser Emission

- (1) Check if gas supply is connected, and set pressure reducing valve reaches 0.2Mpa.



- (2) Check if Laser enable is not turned on.



- (3) Check if grounding clamp properly attached(During welding, clamp to the work piece, during cleaning and

cutting, clamp to the metal part of the gun.).



6.2 The Welding Machine Can Not Continuously Welding


(1) The welding material does not conduct electricity well:

Solution: Clamp the safety clip to the metal position of the gun head to test whether the light can be emitted normally



(2) See if the system set to “spot welding” mode.

Solution: Change the welding mode to :Continuity



6.3 The Welding Is Not Firm or With Ugly Result.

- (1) Check whether the gas is connected.
 - (2) Check whether the parameter settings are incorrect. If the welding is weak, then increase the power or slow down the speed.
 - (3) Check whether the welding material is selected correctly, such as welding object is steel 304, then choose the steel 304 welding wire.
 - (4) Check whether the focal length is incorrect.
 - (5) Check whether the protective lens is damaged.
1. You can also contact the corresponding after-sales service personnel directly for related questions.

6.4 Product common problems and treatment measures

Warning! Before dealing with any problem, all power must be cut off to avoid any danger!

The repair and maintenance of this product must be completed by professional personnel!

Do not operate without training! Please contact your dealer for a professional to handle any problems! Repair can not solve the problem of product appearance. Common alarm descriptions and problem solving measures are as follows:

Problem item	Phenomenon	Solution
Temperature alarm, prompting all kinds of temperature is too high	Home page prompts XXX temperature is too high	General lens temperature alarm, usually first check whether the lens is damaged, replace the damaged lens. If the lens is normal, you need to shield this alarm directly in the setup page, set the corresponding lens temperature alarm threshold to 0 in the setup page to save.
Chiller/Laser/Air Pressure Alarm	Home pop-up window shows laser/air pressure alarms	Alarm logic of the level: the system will compare the wiring of the corresponding product with the level set in the setting page, and the alarm will be raised if it is different. Usually, the alarm occurs because the alarm level is set wrongly, so you can change the corresponding alarm level. If the alarm occurs when there is an alarm signal connected and the alarm occurs no matter how to set the alarm, please unplug the alarm signal wire and set it to low level.
Poor soldering effect	Starts with a strong light and slowly gets weaker/weaker, making it impossible to fuse the wire.	This is usually caused by damage to the lens of the welding gun, including but not limited to the protective lens, focusing, collimation and reflection, any one or more of which may be damaged. Replace the protective lens and look at the focus, then check the reflection and collimation, and replace the damaged lens. About the copper nozzle at the spark may be the focus problem, should be ruled out first. Also check if the laser fibre head part is dirty or damaged.
Motor does not swing	Spot for a point	First, whether the software part of the correct settings Settings -scanning correction: 1.0 or 1.25 Process -scanning width: greater than 0 Home-Indication red light: line Second, the hardware part of the check (first installation) Motor drive for the motherboard 24V power supply, we should first measure the [laser head] interface [24V output] [GND] is normal. This interface controls whether the motor can swing.

<p>Motor swing abnormal</p>	<p>①after power on the welding head tail motor whistling/ swinging red light anomaly/ heat /can not adjust the swing width ②Directly burned lens, sealing ring and focusing lens burned at the same time</p>	<p>The [RS485A][RS485B]of the [laser head]interface controls the motor swing width,speed and other parameters.Problems such as ①may occur when there is a signal error (poor wire contact,disconnection),external interference,or when the driver does not match the motor. If the problem of ②occurs,it is recommended to check the surrounding sources of interference,if there is no source of interference,it may be the motor cable failure, directly replace the motor cable can be.</p>
-----------------------------	--	--

7. After-sales Statement

Warranty period: The machine with a warranty of 12 months from the date of purchasement.

Technical support: We provide free technical support whole lifetime. Any questions please contact the corresponding after-sales service department.

Repair service: Free repair during the warranty period, and appropriate fees will be charged out of the warranty.

Warranty range: We provide warranty services for products with defects caused by materials or production processes during the warranty period, and guarantee that the products meet the relevant quality and specification requirements mentioned in the document under normal use.

We provide repair or replacement services for the machines that fail due to materials or production processes during the warranty period. After repair or replacement , the machine still hold the remaining warranty period.

We do not provide warranty for following situations:

- (1) Any tampering, opening, disassembly or modification on machines by personnel without the permission of our company;
- (2) Damages caused by improper use, negligence or accident;
- (3) Operation beyond the scope of machine specifications and technical requirements;
- (4) Indirect damage to the laser source due to failure of user's software or interface;
- (5) Use due to improper installation, maintenance or other abnormal operating conditions not included in this manual;



(6) Consumables are not covered by the warranty.

Customers are responsible for understanding the above information and operating in accordance with the user manual, otherwise the failure caused will not be covered by the warranty.

Important:

- © Within warranty, customers must provide feedback within 30 days of discovering the fault.
- © Shenzhen Scotle Technology Group Ltd. does not grant any third party or individual the right to repair or replace our products.
- © To protect your rights, please be sure to contact the relevant after-sales department of our company as soon as possible after discovering the fault and apply for product repair or replacement service. If you need to return the product, please pack it in matching packages after authorization by our company and then return it to the place designated by our company.
- © When any damage is found after receiving the product, you must keep the proof document so that we can claim rights from the transporter.
- © Please do not send any product back to our company or any warehouse address without communication and confirmation.
- © If the product is not within the warranty period or warranty scope, users need to pay the product repair costs.